

KABELFERNSEHANLAGE URSERN

Frequenztabelle Fernsehprogramme

<u>Nr.</u>	<u>Sender</u>	<u>Frequenz</u> (MHz)	<u>Kanal</u>
	SF 1	175.25	K05
	SF 2	133.25	S05
	SF info	551.25	K31
	Star TV	161.25	S09
	ARD	189.25	K07
	ZDF	224.25	K12
	ORF 1	203.25	K09
	3+	210.25	K10
	PRO 7	294.25	S20
	SAT 1	154.25	S08
	RTL	245.25	S13
	RTL 2	335.25	S25
	Super RTL	399.25	S33
	Schweiz 5 (U1 TV Station)	703.25	K50
	VOX	343.25	S26
	Kabel 1	391.25	S32
	3sat	266.25	S16
	Tele Tell	140.25	S06
	Eurosport	273.25	S17
	DSF (gleicher Kanal wie HSE 24)	319.25	S23
	HSE 24	319.25	S23
	KiKa (gleicher Kanal wie Arte)	359.25	S28
	Arte	359.25	S28
	Südwest Fernsehen BW	535.25	K29
	VIVA	238.25	S12
	BR	119.25	S03
	TSR 1	196.25	K08
	TSR 2	423.25	S36
	EuroNews	231.25	S11
	France 2	280.25	S18
	TSI 1	217.25	K11
	TSI 2	182.25	K06
	RAI UNO	252.25	S14
	ORF 2	259.25	S15
	CNN	287.25	S19
	TV5 Europe	168.25	S10
	MTV CH (gleicher Kanal wie Nick)	311.25	S22
	Nick	311.25	S22
	MDR	623.25	K40
	NDR	631.25	K41
	N24	639.25	K42
	Infokanal Urserntal	647.25	K43
	n-tv	655.25	K44
	WDR	671.25	K46
	Canale 5	687.25	K48
	Russia	679.25	K47
	Rai 3	695.25	K49

Bei Funkstörung "ZDF" folgende Frequenz verwenden: 799.25 K62